



0925 Splicer

If splicer is too loose in 3/4"
Bullnose, flatten as shown. Attach to bead with Liquid Nails or Drywall Stud Adhesive.