



0924 Splicer

If splicer is too loose in 350 Bull, flatten as shown. Attach to bead with Liquid Nails or Drywall Stud Adhesive.