

T.A.P Panels

Install Instructions

1. Prime panel and frame on all sides to avoid moisture damage.
2. On all four sides, secure frame and drywall to adequate solid framing.
3. Make sure frame is not twisted. Shimming may be required to maintain panel trueness.
4. Pre fill large gaps between drywall and frame.
5. Set tape using paper tape only
6. Use all-purpose compound or Durabond 45 or 90.
7. Finish as you would your taping.
8. Magnet panels are for wall application only.

Do Not Use Fiber Tape, Light Compound or Fast Setting Sandable 20, 45, or 90.

HAMMERHILL Diversified Ltd.



www.tap-panel.ca