Product Comparison Guide

	Titebond® GREEN <i>choice™</i> Advanced Polymer Panel Adhesive	Titebond® GREEN <i>choice</i> ™ Fast Grab FRP Adhesive	Titebond®Solvent-Based FRP Adhesive
Application Recommendations	Porous and most non-porous substrates Interior and exterior applications Fiberglass faced and mold resistant drywall, fire rated and pressure treated plywood, drywall, steel, foamboard, vinyl, PVC, FRP, ceramic tile, laminate, sealed and unsealed concrete	 Porous substrates Interior drywall applications Non-treated plywood, greenboard, non-painted or unsealed concrete 	 Porous substrates Interior and exterior applications Fire rated and pressure treated plywood, drywall, greenboard and unsealed cement
Cure Process	Cures as moisture penetrates the adhesive (reactive)	Dries as water leaves adhesive	Dries as solvents leave adhesive
Open Time	20 minutes	20 minutes	20 minutes
Application Temperature	50 - 90°F	50 - 90°F	50 - 90°F
Benefits	 Easy to trowel Quick grab VOC-compliant Nonflammable Mold & mildew resistant Fast strength development 	 Quick grab formula - requires minimal bracing VOC-compliant Nonflammable No offensive odor Environmentally safe Easy to trowel 	Unaffected by moisture and high humidity Easy to trowel Will not become hard or brittle Excellent wet out
Coverage	3/16" W x 1/4" D x 11/16" c-c V-notch Approximately 60 sq. ft. per gallon 3/16" W x 1/4" D x 1/2" c-c V-notch Approximately 50 sq. ft. per gallon	3/16" W x 1/4" D x 1/2" c-c V-notch Approximately 50 sq. ft. per gallon	3/16" W x 1/4" D x 1/2" c-c V-notch Approximately 50 sq. ft. per gallon
Cleanup	It is important to clean-up adhesive immediately while still wet. To clean adhesive from panel, tools and hands while wet, use mineral spirits and a rag. Once adhesive has cured, it can be extremely difficult to remove. Follow solvent vendor's precautions. NOTE: Test solvent in an out-of-the-way area to make sure it will not mar or attack the surface.	Tools and excess adhesive may be cleaned with water while wet. If adhesive has dried, use mineral spirits. Follow solvent vendor's precautions when using solvents. NOTE: Test solvent in an out-of-the-way area to make sure it will not mar or attack the surface.	Scrape off dried excess with a putty knife. Remove residue with mineral spirits or equivalent solvent while the adhesive is still wet. Follow solvent vendor's precautions when using solvents. NOTE: Test solvent on an out-of-the-way area to make sure it will not affect the surface being cleaned.
Specifications	Meets GreenSeal GS-36, LEED, SCAQMD, CARB and NAHB Green Building specifications.	Meets GreenSeal GS-36, LEED, SCAQMD, CARB and NAHB Green Building specifications. FDA and Canadian Food Inspection Agency (CFIA) approved for indirect food contact.	N/A

Project Help Line

Technical Support 1.800.347.4583 Customer Service 1.800.669.4583 www.titebond.com www.TitebondGreenChoice.com

